



Plasmon LMS Inc.

---

# Technical Bulletin

**PRODUCT MODEL NAME: LM4000/LM6000/LM8000 Media Cleaning Kit**

**DATE: 03/30/01**

**Technical Bulletin Number: O-033001-A**

---

## ***Reason for Bulletin***

It has been discovered that plasticizers are leaching into the cleaning solution, leaving a thin plastic film on the media during the cleaning process.

Therefore, more safer, thorough and convenient method of cleaning the LM 4000, LM 6000 and the LM 8000 media is being implemented.

The cleaning solution provided with the Media Cleaning Kit (P/N97662550) has been replaced by individually packaged cleaning pads. The cleaning pads provided in the kit are pre-soaked with a cleaning solution.

## ***Part number(s) for the affected part***

Media Cleaning Kit, P/N97662550

## ***Procedure for the Preventative/Corrective Action***

Dispose of the bottle of cleaning solution and use only the cleaning pads supplied with the cleaning kit or the replacement cleaning pads.

## **Disposal Considerations**

### **NOTE:**

The Cleaning Solution contains Methanol. Refer to **Material Safety and Data Sheet (MSDS)** for proper disposal instructions of this cleaning solution.

All residual vapors from "empty" container should be allowed to evaporate before discarding. Applications and/or contaminated absorbent material which contain product in the amounts accumulated during specific usage may be deposited in a landfill in accordance with **local, state and federal** authorities.

For more information about this product contact:

PHOTOGRAPHIC SOLUTIONS, INC  
7 GRANSTON WAY  
BUZZARDS BAY, MA 02532-4914  
Phone: (508) 479-2322  
URL: <http://www.photographicsolutions.com/tech.html>

For media cleaning instructions, refer to the *12 in Media Cleaning Instructions Sheet* (P/N97662549 Rev C).

**Contact information for technical questions:**

Plasmon LMS Technical Support Team  
Unites States Calls – 1 – 877 – 585 – 6793  
International Calls – 719 – 593 – 4437  
FAX (719) 593-4192  
Email: tech.support@lms.com  
WEB PAGE - [www.plasmon.com](http://www.plasmon.com)