

UDO60I SCSI Quick Start

Software drivers, and User Manuals for both the UDO™ drive and the software, is provided on the enclosed UDO Drive Resource CD.

Set Up

Before applying power:

1. Set SCSI ID (factory default is ID1)
2. Mount in system enclosure (horizontal, or vertical w/power connector up)
3. Connect flat SCSI cable
4. Connect power cable and apply power
5. Install appropriate software driver

CAUTION



Do not insert media into the UDO drive until the appropriate software driver is installed.

New media must be formatted prior to use. Refer to the software documentation on the enclosed CD.

Contacting Plasmon

First, register on-line at <http://plasmontech.com/warranty/index.html>.

	In the US	In Europe
Technical Support	+1-877-585-6793	+44 (0) 1763 262 963
fax	+1-719-593-4192	+44 (0) 1763 264 444
e-mail	tech.support@plasmon.com	support@plasmon.co.uk
World Wide Web	www.plasmon.com	www.plasmon.co.uk
Asia/Pacific, South America, and Canada		
International Calls	+1-719-593-4437	
fax	+1-719-593-4192	

UDO60I SCSI Quick Start

Software drivers, and User Manuals for both the UDO™ drive and the software, is provided on the enclosed UDO Drive Resource CD.

Set Up

Before applying power:

1. Set SCSI ID (factory default is ID1)
2. Mount in system enclosure (horizontal, or vertical w/power connector up)
3. Connect flat SCSI cable
4. Connect power cable and apply power
5. Install appropriate software driver

CAUTION



Do not insert media into the UDO drive until the appropriate software driver is installed.

New media must be formatted prior to use. Refer to the software documentation on the enclosed CD.

Contacting Plasmon

First, register on-line at <http://plasmontech.com/warranty/index.html>.

	In the US	In Europe
Technical Support	+1-877-585-6793	+44 (0) 1763 262 963
fax	+1-719-593-4192	+44 (0) 1763 264 444
e-mail	tech.support@plasmon.com	support@plasmon.co.uk
World Wide Web	www.plasmon.com	www.plasmon.co.uk
Asia/Pacific, South America, and Canada		
International Calls	+1-719-593-4437	
fax	+1-719-593-4192	